



Nanocomposite Silica Thin Films



¹Lu *et al.* *Nature* **1997**, **389**, 364.; ²Parikh, *et al.* *Chem. Mater.* **2000**, **12**, 3879.


Patterned Mesoporous/Mesostructured Films

Pattern Generation and Enhancement³




³Dattelbaum, *et al.* *Nanoletters* **2003**, in press.

Characterization by FTIR and Ellipsometry of Enhancement




Functionalization of Patterned Nanocomposite Thin Films



Substrate-Supported Membrane Assemblies

Types of Membrane Assemblies





Applications Include:

- Biosensor platforms
- Prevention of biofouling
- Protein and receptor presentation
- Cell-surface interactions
- Fundamental membrane biophysics
- Membrane-protein interactions

Applications require control of **patterning** and **lateral fluidity**




Fluorescence Recovery After Photobleaching (FRAP)



Preparation of Membrane Assemblies

- Vesicle Fusion**
 - Phospholipid vesicles (with ≤1% fluorescently labeled lipid) prepared in buffer at controlled ionic strength and pH
 - Vesicle solution contacted with substrate; Incubate ≥30 minutes
 - Exhaustively rinse with buffer
 - Store under buffer solution (indefinitely)
- Langmuir-Blodgett**
 - Prepare phospholipid monolayer (with labels) at air-water interface
 - Sequential horizontal or vertical transfers at controlled π, T, sub-phase pH
 - Can prepare assemblies "wet" or "dry" and store in corresponding conditions
- Modifications**
 - Polymer supports
 - Substrate choices
 - Patterning

FRAP Data for Supported Bilayer (Texas Red DHPE Label)



Recognition of Patterned Self-Assembled Surfaces

